






	Units with terminal block on the compressor	Units with connecting box standard model	Units with connecting box "3P" model	Units with 3 Phase connecting box
CSIR				
RSIR				
CSR				
3 PH				